

3mm LED Install for CAPI VP25, VP26 or VP312

The LED install is pretty easy. I do it before the phantom switch is installed. The best way is to have the PCB, L-bracket and faceplate assembled. Just fit the LED into the faceplate and bend the leads as required using a needle nose pliers. The leads can be cut so they only go thru the PCB a little bit. Then solder from the top. Just remember that the shorter lead goes to the hole that the arrow is pointing to. If you get done and the LED doesn't illuminate, it is most likely because it's backwards.

